

Before You Begin

- Verify all of the contents of your pack
- Review safety guidelines in User's Manual
- Place LCD TV so the rear connectors are accessible
- Install AAA batteries into the ELEMENT Remote Control
- Write down your 42LE45Q Serial Number (located on the back)

Contents:



Remote Control
Includes 2xAAA Batteries



Power Cord



Documents
User Manual, Warranty Card,
Warranty Registration and
Quickstart Guide

The Best Connection:

We highly recommend you use HDMI and ANT(DTV) whenever possible. Please keep in mind however that not all components are capable of this type of connection. Our color-coded chart will help explain which components are capable of connecting in HDMI and ANT (DTV). To receive HDMI or component video must be used. To receive HD programs from an antenna use ANT (DTV) input. Standard TV, AV or S-Video cannot pass HDTV signals.



Four Easy Steps Simply follow our color-coded Step Charts and you're done

1) Choose items to connect to your 42LE45Q

- Determine which type of Signal Source and any Additional Equipment you wish to connect to your 42LE45Q
- The colored dots under each Signal Source and Additional Equipment indicate which type of connections you may use to connect to your 42LE45Q

| Signal Sources | Additional Equipment |
|----------------|----------------------|
| Antenna | Computer |
| Cable Box | Digital Camera |
| Digital Cable | DVD |
| Satellite Box | DVR |
| | Game System |
| | Sound System |
| | VCR |
| | Video Camera |

2) Choose Equipment connection methods

- Using the colored dots from Step One, follow the row across to Step Two to match up the colored dots to the same colored connection method.
- Choose ONLY one method for each piece of equipment.

3) Select cables and make connection

- Once you have determined the connection methods from Step Two, follow the row to Step Three to determine what a kind of cables you need and what the connections look like on your equipment.


- Following the color-coded system, use the appropriate cables and connect your Signal Source and Additional Equipment to the color-coded inputs on your 42LE45Q (Refer to Connection Map at bottom of page.)

- Once connected, turn on your 42LE45Q and all your equipment.

4) Use your 42LE45Q

| Connection Methods | Cable Needed | Connection Methods | My 42LE45Q has | Connection Reference |
|---|------------------------------------|--------------------|---------------------------------|------------------------------------|
| HDMI Type: Digital High Definition QUALITY: Best Digital | HDMI* HDMI Cable* | | HDMI-1 HDMI-2 HDMI-3 | HDMI Connected Equipment |
| COAX Type: Digital Audio Out QUALITY: Best Analog | Coaxial(RF) Cable* | | COAX | COAX Connected Equipment |
| VGA Type: RGB Analog QUALITY: Best Analog | VGA Cable* & Audio mini-jack | | VGA Audio Input | VGA Connected Equipment |
| COMPONENT 1 Type: Component Analog QUALITY: Best Analog | Component & RCA Cable* | 1 2 3 4 5 | Y1 Pb1 Pr1 Y2pb1-L Y2pb1-R | COMPONENT 1 Connected Equipment |
| COMPONENT 2 Type: Component Analog QUALITY: Best Analog | Component & RCA Cable* | 6 7 8 9 10 | Y2 Pb2 Pr2 Y2pb2-L Y2pb2-R | COMPONENT 2 Connected Equipment |
| AV1 Type: Analog QUALITY: Good Analog | AV RCA Cable* or S-Video Cable* | 11 12 | CVBS1 Video1-L Video1-R S-Video | AV1 Connected Equipment |
| AV2 Type: Analog QUALITY: Good Analog | AV RCA Cable* | 13 14 | CVBS2 Video2-L Video2-R | AV2 Connected Equipment |
| TV Type: Antenna/RF Cable QUALITY: Good Best | Coaxial(RF) Cable* | | TV | TV Connected Equipment |

Rear Connectors Instruction



* RF Cable ,HDMI Cable , VGA Cable , Audio mini-jack, Component Cable and Coaxial Splitter are not included.

INPUT Menu

| Source |
|-------------|
| ✓ TV |
| AV1 |
| AV2 |
| S-VIDEO |
| Component 1 |
| Component 2 |
| VGA |
| HDMI 1 |
| HDMI 2 |
| HDMI 3 |

Program your TV (continued)

Programming your 42LE45Q is a simple TWO STEP process.
All you need is your Remote Control

STEP 1

If you connected your Signal Source to the TV
(Regular Cable/ Antenna), go to STEP 2a.

STEP 1

If you connected your Signal Sour to the TV
(Digital Antenna/Cable), go to STEP 2b

STEP 2a

TV

(Regular Cable/Antenna)

On your Remote Control...

1. Press the [MENU] button to show the ON SCREEN DISPLAY menu.
2. Press the [▲ / ▼] button to enter the [TV]
3. Press the [ENTER] button to select AIR or CABLE.
4. Press the [▲ / ▼] button to highlight [CHANNEL SCAN] to scan the available channels
5. Use the [▶] button to start the scan, Scanning for available channels could take several minutes.
6. Once scanning is finished, programming is complete.
7. Press [MENU] button until ON SCREEN DISPLAY menu disappears.



For advance set ups, refer to your 42LE45Q User Manual


STEP 2b

DTV

(Digital Cable/Antenna)

On your Remote Control...

1. Press the [MENU] button to show the ON SCREEN DISPLAY menu.
2. Press the [▲ / ▼] button to enter the [TV]
3. Press the [ENTER] button to select AIR or CABLE.
4. Press the [▲ / ▼] button to highlight [CHANNEL SCAN] to scan the available channels
5. Use the [▶] button to start the scan, Scanning for available channels could take several minutes.
6. Once scanning is finished, programming is complete.
7. Press [MENU] button until ON SCREEN DISPLAY menu disappears.



For advance set ups, refer to your 42LE45Q User Manual